


General Force CU 100-V63



- | | | | | |
|-----------------------|----------------------|------------------------|-------------------------|---------------------|
| 01 crankcase | 18 valve plate | 35 connecting rod | 52 flywheel flat gasket | |
| 02 oil plug | 19 valve plate | 36 nut | 53 bolt | 68 pressure gauge |
| 03 oil sight seal | 20 exhaust limiter | 37 flat gasket | 54 belt guard | 69 connecting bolt |
| 04 oil viewer | 21 head cover gasket | 38 spring washer | 55 bolt | 70 pressure gauge |
| 05 screw | 22 head cover | 39 bolt | 56 flat gasket | 71 safety valve |
| 06 spring gasket | 23 air filter | 40 bearing | 57 belt | 72 motor power cord |
| 07 real cover | 24 bolt | 41 washer | 58 key | 73 power cord |
| 08 real cover gasket | 25 spring washer | 42 crankshaft | 59 motor pulley | 74 nut |
| 09 breather | 26 tee connect | 43 key | 60 motor | 75 tube |
| 10 cylinder gasket | 27 exhaust pipe | 44 bearing | 61 nut | 76 elbow |
| 11 cylinder | 28 exhaust elbow | 45 oil seal | 62 flat gasket | 77 check valve |
| 12 spring washer | 29 T connect | 46 bearing seat gasket | 63 spring washer | 78 exhaust pipe |
| 13 bolt | 30 compressor ring | 47 bearing seat | 64 bolt | 79 tank |
| 14 nut | 31 oil ring | 48 spring washer | 65 pressure switch | 80 support |
| 15 admission valve | 32 piston | 49 screw | 66 air valve | 81 nut |
| 16 location pin | 33 piston pin | 50 breather | 67 regulator | 82 spring washer |
| 17 valve plate gasket | 34 pin clip | 51 flywheel | | 83 flat gasket |
| | | | | 84 bolt |
| | | | | 85 protector |
| | | | | 86 drain valve |
| | | | | 87 wheel |
| | | | | 88 flat gasket |
| | | | | 89 split pin |
| | | | | 90 air valve |